










REPLENISH RECEIPT PAPER

NOTE: THIS PROCEDURE REQUIRES TERMINAL IS POWERED UP.

STEP	ACTION	STEP	ACTION	STEP	ACTION
1	CUT REMAINING PAPER TO ALLOW REMOVAL.	2	PRESS FEED BUTTON TO CLEAR PAPER FROM PAPER PATH.	3	LIFT SPINDLE TO REMOVE PAPER ROLL AND SPINDLE.
					
4	REMOVE OLD PAPER ROLL. PLACE SPINDLE IN NEW PAPER ROLL.	5	PLACE NEW PAPER ROLL ON BRACKET. MAKE SURE PAPER FEEDS FROM BOTTOM!	6	FEED END OF PAPER INTO FEED SLOT.
					
7	PAPER WILL FEED AUTOMATICALLY INTO PRINTER.	8	(OPERATOR SERVICE PANEL PRINTING) GRASP HANDLE AND PULL RELEASE PIN.	9	(OPERATOR SERVICE PANEL PRINTING) ROTATE PRINTER ASSEMBLY UP AND RELEASE PIN.
					

For more information or assistance, please call **cashline** 1-888-870-9780